




JOB MANAGEMENT APPARATUS 40




FNSEA048
FIG.2







FNSEA048
FIG.4




FNSEA048
FIG.5




FNSEA048
FIG.6



FNSEA048
FIG.7











FIG.10




FNSEA048
FIG.11



FNSEA048
FIG.12










FIG.15


The diagram shows a "Job Export" dialog box with a title bar and a close button. The dialog contains three input fields: "Output Destination:" (130), "Job File Name:" (131), and "Comment:" (132). A "Settings" button is located to the right of the "Output Destination:" field. A large text area (133) is positioned below the "Comment:" label. At the bottom of the dialog are three buttons: "OK", "Cancel", and "Help". A reference numeral 134 points to the right side of the dialog box.

FNSEA048
FIG.16



FNSEA048
FIG.17










FIG.20


JOB NUMBER
OUTPUT SOURCE
OUTPUT DESTINATION
JOB FILE NAME
JOB FILE STORAGE LOCATION
COMMENT STORAGE LOCATION
DATE AND TIME OF RECEPTION
DATE AND TIME OF TRANSMISSION



FNSEA048
FIG.22



FNSEA048
FIG.23



FNSEA048
FIG.24

